



User Manual of Solder Printer


I. Installation Instruction:




1.) Install screw lever, wire clip, fixed block and counterweight lever in sequence according to the graphic presentation above.

2.) Rotate counterweight lever while adjusting tight nut.

II. Operation Instruction:



1.) Put steel stencil in the wire clip, and tighten the steel stencil by its handwheel.



2.) Put the simple DIY positioner on the printing table and also put the PCB accordingly. Adjust the five-star handle on the operation platform to make the holes on PCB match the holes on the steel stencil.